




## STORM SYSTEM®

The Storm Small Long is part of the STORM SYSTEM® collection. A collection that includes a wide range of special designed products. The STORM SYSTEM® collection is carefully designed to flush the surface of any ceiling or wall, and all products will appear with an absolute minimum of tolerance and visibility.

The light fixture is designed to rotate 360° and allows a 23° adjustment along the.



The crossed-out wheeled bin symbol indicates that the item should be disposed of separately from household waste. The item should be handed in for recycling in accordance with local environmental regulations for waste disposal

For more information, please contact [info@onea.dk](mailto:info@onea.dk)

# STORM SMALL LONG

## DATA

Collection	STORM SYSTEM®
Product	Storm Small Long
Article no.	1A00.0103.xx04

## SPECIFICATIONS

Weight	160 g
Material	Aluminium
IP protection grade	IP20
Labelling	CE
Safety distance	0,3m
Insulation class	Class III
Fixture finish	For xx-codes review STORM SYSTEM® – COLOUR CODES ➤
Supply	Constant Current LED max. 5W

## ADDITIONAL REQUIREMENTS

Light Source MR11 LED (light source not included)  
review CONFIGURATION ➤


For IES/LDT lux files review  
STORM SYSTEM® – LUX FILES ➤

NOTE: when using honey combs the light output will fall with 30% in efficiency

This product shall always be powered by SELV LED driver, output voltage of this driver in open circuit must not exceed 60V. Do NOT cover the LED driver or locate LED driver on top of light fixture.

## INSTALLATION DEPTH

Be aware – external driver location is recommended.  
For specific light source conditions – review CONFIGURATION ➤



## IMPORTANT INFORMATION

Installation and mounting must be performed by a certified electrician only, and instructions must be followed.

Always make sure the main power is off during installation. Pay attention to the fixture remarks, and always make sure to use the correct voltage.

## CLEANING AND MAINTENANCE:

Use a soft moist cloth for cleaning. No further maintenance is required.

**WARRANTY:** If the product is defect, please contact your supplier immediately. Please note that warranty will not apply in case of wrongful use or if unskilled personnel attempts to repair.

## COMPONENTS

- Storm Small Long
- Spring
- Honeycomb



## PLEASE NOTE:


If the spring on the fixture is damaged, do not proceed installation – contact your dealer!

# STORM SMALL LONG

## ASSEMBLY INSTRUCTION


### STEP 1

Pull back the spring




### STEP 2

Mount your chosen light source or socket, guide the wire/socket through the hole in the base of the fixture



### STEP 3

Mount the Storm Long Tube, by gently rotating the tube into place.




### STEP 4

Connect the supply cable with Storm Small Long's cable, then mount the fixture into the plaster ring/back-mounted ring. Do this by slightly rotating the fixture.

**BE ATTENTIVE!** Make sure you are using the correct power supply according to the fixture.

**NOTE:** When rotating the fixture choose the direction with the least resistance.



#### IMPORTANT INFORMATION

Disassembly must be performed by a certified electrician only, and instructions must be followed.

#### WARRANTY:

If the product is defect, please contact your supplier immediately. Please note that warranty will not apply in case of wrongful use or if unskilled personnel attempts to repair.


## STORM SMALL LONG

### DISASSEMBLY INSTRUCTION

#### STEP 1

Take hold of the fixture and pull down gently, whilst slightly rotating.

NOTE: When rotating the fixture choose the direction with the least resistance.



#### STEP 2

Disconnect the cables.

