

acrotrack 48V

installation instruction



POWER OFF

slide the luminaire in the prado 48V track make sure to use a prado 48V LED-driver



thank you for choosing prado



prado.eu

The light source in this luminaire shall only be replaced by the manufacturer or a similar qualified person. Warranty will not apply in case of wrongful use

or if unskilled personnel attempts to repair the product.